

Pannello Sospeso Assembly Instructions

Tools Needed

- 1 Ceiling screws (appropriate for ceiling type)
- 2 Allen wrench
- 3 Instant adhesive

Components Provided (per panel)

One acoustic panel
Two 9'-10" (3 m) lengths of steel cable
Four transition sleeves

Assembly Instructions

- 1 Attach metal sleeve to the ceiling using appropriate screw for ceiling type. (Ceiling screws not included.)
- 2 Insert steel cable through the counterpart and screw into metal sleeve.
- 3 Screw steel cable holder into panel.
- 4 Insert steel cable and adjust panel. Shorten the steel cable to 3/8 in (1 cm). Fix the cable connection with instant adhesive.

