

Pannello Supporto Assembly Instructions

Tools Needed

- 1 Ceiling screws (appropriate for ceiling type)
- 2 Allen wrench

Components Provided (per panel)

- One acoustic panel
- Two screws
- Two powder-coated steel feet

Assembly Instructions

- 1 Insert panel into stand and screw into place using screw provided and allen wrench.
- 2 Repeat with second foot.

