

# Rille Installation Instructions

These installation recommendations consist of common-sense practices for direct-glue wall-to-wall panel products. Installers should rely upon their own professional experience and understanding of their unique requirements to be the best guide to a successful installation.


## Tools Needed

- 1 Bar level or laser level
- 2 Heavy-duty construction adhesive (such as Liquid Nails FRP or Loctite Express – All purpose)
- 3 1/8 inch V-notch trowel
- 4 Utility knife and blades
- 5 Carpenter's square
- 6 Weighted roller

It is recommended that you have access to warm soapy water in the event of getting adhesive on the front of the panel. Any adhesive must be removed with warm soapy water before the adhesive has dried.

## Components Provided

Rille Panels (as ordered):



Note: Rille 5 and Rille 6 are asymmetrical designs. Refer to FilzFelt shop drawing for correct orientation prior to installation.

## Installation Instructions

- 1 Handle the panels individually and with clean hands to reduce the possibility of damage during installation.
- 2 Inspect the material. Subtle color and texture variations even within the same panel are a normal aspect of this product. It is advisable to inspect for these irregularities and plan the layout accordingly making sure to evenly disperse any minor color variation. In the case of product defect or damage in transit, FilzFelt must be notified within five business days. Please note that FilzFelt cannot accept a return or warranty claim on any material that has been installed.
- 3 Allow components to acclimate to the installation environment. After the shipping crates have been opened, the panels should be laid out individually on the floor for at least forty-eight (48) hours.
- 4 While the panels are becoming acclimatized, clean the work surface. It should be smooth, dry and dust free to allow the best possible adhesion. A Level 4 Finish wall preparation is sufficient.
- 5 Use the bar level or laser level to determine a base level line for the panels. This line will set the level for the entire installation so it is most important to get this right. Consider whether you will be scribing to the ceiling or floor or both BEFORE setting this level line.
- 6 Refer to FilzFelt shop drawing to use as a guide for panel placement and orientation.
- 7 To install the first panel, apply adhesive directly to the wall area to be covered by the panel using an 1/8 inch V-notch trowel. Apply firm pressure using a weighted roller to ensure good adhesion. Installation of this product using caulking guns is not recommended as uneven adhesive application could telegraph through the panel.
- 8 Use a carpenter's square and sharp utility knife to cut any custom sizes or outlet cut-outs needed to finish the installation.
- 9 Allow the first panel to set up (approximately 20 minutes) before installing adjacent panels.
- 10 Move along the wall following the above procedure, making sure that the panels are butted firmly against one another. Continue checking level throughout installation. Repeat until complete.

## Cleaning Instructions

---

Like any natural fiber, a minimal approach should always be taken to clean wool felt since the cleaning method could potentially do more damage than the stain. In this order, the cleaning approach should be: dusting with a roller, vacuuming with a clean soft brush, water and mild detergent, chemical spot remover. If a chemical spot remover is required, test first in an inconspicuous area.

Where wool felt is used as a wall and ceiling application, periodic spot removal of lint can be achieved easily by using a standard masking tape lint roller. It is always a good idea to use the lint roller first in any area intended to be spot cleaned. Once per year, it is recommend that the entire surface be given a light vacuum with a soft horsehair upholstery brush. In a clean office environment, it may not be necessary to do this annually.

For removal of minor stains, a mild enzyme-based detergent (such as Tide Free) is recommended. Create a dilute solution by adding three parts water to one part detergent in a clean container. Use a clean paper towel to gently blot the detergent into the stain. Press and release, press and release. Using a separate container of just clear water, use clean moist paper towels to blot more water into the stain. Press and release, press and release. Finish by blotting firmly with clean, dry paper towels until the area is nearly dry.

There are many solvent-based spot removers available. Although they are not recommended except in the case of emergency, the best choices for wool felt are dry cleaning fluids. Be sure to test in an inconspicuous area first. Blot the stained area with a clean cloth soaked in dry cleaning fluid, then blot with clean cloth until dry.