

Silento Murale Assembly Instructions

Tools Needed

- 1 Wall screws (appropriate for wall type)
- 2 Allen wrench

Components Provided (per panel)

One acoustic panel with two nylon straps
Two Z-profiles
Two U-profiles

Assembly Instructions

- 1 Screw U-profiles into the wall with wall screw appropriate for wall type. These are positioned at the base of the panel.
- 2 Screw Z-profile into the wall with wall screw appropriate for wall type. These are positioned at the top of the panel.
- 3 Slide the acoustic panel sideways, from left to right, through the nylon straps over the Z-profiles.
- 4 Rest the acoustic panel in the U-profile.

