



Link Assembly Instructions

Components Provided (per panel)

Header(s) with velcro (as ordered)





Modules (as ordered)



Please note correct orientation of each module design

Assembly Instructions

- 1 Lay header velcro side down.
- 2 Ensure orientation of each module is correct. Align top Module Tab with corresponding Header Slot. Insert Module Tab into Header Slot and pull tab through so that Module Tab is exposed on the front side.



- 3 Continue connecting Modules down the entire length of column.
- 4 For the subsequent columns, connect top Module Tab into Header Slot, then connect sides.
- 5 To connect Linking Header, butt Linking Header to assembled Linking Header. Connect first Module to Linking Header and to adjacent Modules.

