

Pannello Tavola Assembly Instructions

Tools Needed

- 1 Pencil
- 2 Allen wrench
- 3 Screw clamp

Components Provided (per panel)

One acoustic panel
Two magnets
Two magnet caps
Two adhesive circles

Assembly Instructions

- 1 Fit magnet cap over magnet and screw into each foot. Apply the two adhesive circles to the magnet, positioning them centrally.
- 2 Clean the tabletop surface thoroughly, ensuring that there is no greasy residue. The adhesive circles are also suitable for use with slightly porous surfaces.
- 3 Mark the desired positions of the feet on the tabletop with a pencil.
- 4 Carefully remove the protective paper from the adhesive circles and stick the feet in the marked positions.
- 5 Press the panel down firmly, exercising maximum pressure for one or two minutes. The pressure must be applied evenly—it is essential to avoid tilting the panel to the side. The panel should remain in close contact with the adhesive circle for at least 24 hours (ideally for 48 hours).
- 6 After 24–48 hours, tilt the panel to the side and further secure the adhesive circles to the table with the help of a screw clamp. For slightly porous surfaces, curing for an additional 24 hours is recommended. Finally, the panel can be repositioned on the circles.

Note: The adhesive cures and develops its full strength after 14 days.

Disassembly Instructions

- 1 Tilt the panel to the side and then remove the adhesive circles from the surface with the help of hot air (i.e. blow dryer).
 - 2 To reinstall the panel in another location, FilzFelt can supply additional double-sided adhesive circles.
- Note: All adhesive residue must be removed from the magnet cap with a standard solvent before the new adhesive can be applied.

